


DK-004MULTI-PURPOSE CARTS USER GUIDE


- Thank you for purchasing the DK-004 multifunctional cart. Please read this manual carefully before using the cart to fully understand its installation methods and functions. Keep this manual properly for reference at any time.
- In order to continuously improve the product, the company reserves the right to update or modify the information

Installation instructions


1. Install the A base casters and pay attention to the installation of the universal wheels.




2. Place the B frame on one end of the universal wheel on the A base and tighten the screws




3. Connect the C frame to the B frame and the A base, and tighten the screws




4. Connect D frame and E frame to B frame and A base




5. Connect the F frame to the C, D, E frames and A base Tighten the screws



6. Connect the G top plate to the B, E, and F frames and tighten the screws



7. Connect the H and | shelves to the B frame and F frame respectively and tighten all the screws.



Product Specifications

Model No.	DK-004	Net Weight	101.5kg
Diameter	1500*710*1900mm	Load Capacity	300kg

Maintenance

- Regularly tighten screws, rivets, screw rods and other connecting parts to ensure the stability and safety of the cart, and promptly replace any parts in bad condition.
- Please use this product correctly according to the instructions. If the product is damaged, it can be repaired free of charge during the specified warranty period.
- Warranty policy: Under normal circumstances, the warranty is 3 years. For minor problems, spare parts will be free of charge.

 Guidance on replacement, products that cannot be repaired by the client can be

Guidance on replacement, products that cannot be repaired by the client can be arranged to be sent back to the factory for after-sales repair. Product repair or reshipment costs shall be borne by the purchaser.

4 Please note: Any one of the following conditions is not covered by the

The warranty period has expired;

Loss caused by failure to use, maintain, and store products in accordance with the requirements of the product instructions:

Damage and human losses caused by force majeure;